

oatey shower drain installation instructions

Oatey shower drain installation instructions are essential for anyone looking to install a shower drain correctly and efficiently. Oatey is a well-respected brand in plumbing products, known for its quality and reliability. Installing a shower drain can seem daunting, but with the right tools, materials, and step-by-step guidance, it can be a manageable DIY project. This article will provide comprehensive instructions on how to install an Oatey shower drain, covering everything from preparation to finishing touches.

Tools and Materials Needed

Before diving into the installation process, it's crucial to gather all necessary tools and materials. Here's a list to ensure you have everything ready:

Tools

- Measuring tape
- Screwdriver (flathead and Phillips)
- Drill with bits
- Pipe cutter or hacksaw
- Level
- Caulking gun
- Trowel
- Bucket

Materials

- Oatey shower drain kit (includes drain body and cover)
- Drain assembly adhesive or PVC cement (if applicable)

- Shower pan or subfloor material (if needed)
- Waterproof membrane (optional, but recommended)
- Concrete or mortar mix (if installing on a concrete slab)

Preparation Steps

Preparation is key to a successful installation. Follow these steps to ensure the area is ready for your Oatey shower drain.

1. Choose the Right Location

Select a location for your shower drain that aligns with your shower design. Consider the following:

- Ensure the drain is at the lowest point of the shower to promote proper water drainage.
- Take into account any plumbing or electrical work that may interfere with the installation.

2. Prepare the Subfloor

- If you are working on a concrete slab, ensure that the surface is clean and free from debris.
- For wooden subfloors, check for any rotting or damage. Replace any damaged sections before proceeding.

3. Measure and Mark

- Measure the diameter of the drain pipe and mark the area where the drain will be installed.
- Make sure to account for the thickness of the shower pan and any tiles that will be installed.

Installation Steps

Now that you have prepared the area, it's time to install the Oatey shower drain. Follow these detailed steps:

1. Cut the Drain Pipe

- Use a pipe cutter or hacksaw to cut the drain pipe to the appropriate length. The pipe should extend slightly above the finished floor height of the shower pan.
- Clean the edges of the cut pipe to ensure a smooth fit.

2. Position the Drain Body

- Place the Oatey drain body over the pipe, ensuring it is centered and level.
- If you are using a shower pan, ensure the drain body fits snugly into the pre-cut hole.

3. Secure the Drain Body

- If using adhesive or PVC cement, apply it to the outside of the pipe and the inside of the drain body. Slide the drain body onto the pipe and hold it in place for a few seconds to ensure a secure fit.
- If your model has screws, secure the drain body to the subfloor or shower pan using screws provided in the kit.

4. Create a Slope

- To ensure proper drainage, create a slope from the edges of the shower pan to the drain. A slope of 1/4 inch per foot is recommended.
- Use a trowel to spread mortar or concrete to achieve the desired slope around the drain.

5. Install Waterproof Membrane (if necessary)

- If you are using a waterproof membrane, lay it over the shower pan and secure it according to the manufacturer's instructions. Ensure that the membrane extends over the drain body.

Finishing Touches

After the drain body is installed, it's important to make the finishing touches to ensure a seamless and functional shower.

1. Install the Shower Pan

- Place the shower pan over the drain and ensure it fits properly. Follow the manufacturer's instructions for securing the pan in place.
- Ensure that the pan is level and that the water can flow towards the drain.

2. Tile and Grout (if applicable)

- If you are tiling the shower, begin laying tiles from the bottom up, ensuring they fit snugly around the drain.
- Use grout to fill in the spaces between the tiles, and ensure that the grout is applied evenly.

3. Attach the Drain Cover

- After the tiles and grout have dried completely, attach the Oatey drain cover according to the instructions in the kit. This covers the drain and provides a finished look to your shower floor.

Final Checks and Maintenance

Once the installation is complete, it's important to perform some final checks and understand basic maintenance for your shower drain.

1. Check for Leaks

- Before using the shower, turn on the water and let it run for a few minutes while checking for any leaks around the drain.
- If you notice any leaks, you may need to reapply adhesive or tighten screws.

2. Regular Maintenance

- To keep your Oatey shower drain functioning properly, clean it regularly by removing hair and debris.
- Inspect the drain periodically for any signs of wear and tear, and address any issues promptly to prevent larger problems.

Conclusion

Installing an Oatey shower drain may seem like a complex task, but with the right preparation, tools, and clear instructions, it can be accomplished successfully. By following the outlined **Oatey shower drain installation instructions**, you can ensure a functional and aesthetically pleasing shower that will serve you well for years to come. Always remember to prioritize safety and double-check your work to achieve the best results. Happy plumbing!

Frequently Asked Questions

What tools do I need for Oatey shower drain installation?

You will need a tape measure, a level, a hacksaw or pipe cutter, a screwdriver, and plumber's putty or silicone sealant for installation.

How do I prepare the subfloor before installing the Oatey shower drain?

Ensure the subfloor is clean, level, and free of debris. You may need to use a level to check for any high or low spots and make necessary adjustments.

Can I install an Oatey shower drain on a concrete slab?

Yes, Oatey shower drains can be installed on concrete slabs. Just make sure to create a proper slope towards the drain for effective water flow.

What is the correct way to connect the Oatey shower drain to the plumbing system?

Connect the drain to the plumbing using PVC or ABS pipe, ensuring you use the appropriate solvent cement for a watertight seal.

How do I ensure a watertight seal when installing the Oatey shower drain?

Apply plumber's putty or silicone sealant around the flange before placing it into the drain assembly, and tighten the screws evenly to secure it.

Are there specific instructions for different types of Oatey shower drains?

Yes, Oatey offers various types of shower drains. Always refer to the specific installation instructions included with your drain model for best results.

[Oatey Shower Drain Installation Instructions](#)

Related Articles

- [observing and recording the behavior of young children](#)
- [operations with exponents worksheet](#)
- [nursing assistant workbook answer key](#)

[Back to Home](#)